

ADB (BLACK) PBTB REMOTE FOR ADB SETTOPS



THE LEARNING METHOD

Basically, this means that you can transfer the information from the FACTORY ISSUED remote to the ADB remote (power, volume, etc.) It bypasses having to do the code search method.

- Press the **RCU SETUP** until the last selected mode button blinks twice. (TV, DVD, etc.)
- Enter in **9 7 5**
- Press the **TV** button
- Press the button you wish to program (i.e. **POWER**) on the ADB remote
- Place the **ADB** remote and the **ORIGINAL** remote head-to-head about 2 inches apart.
- Press and **HOLD** the **SAME** button (power) on the **ORIGINAL** remote. The ADB remote TV button will blink rapidly and turn off. Keep holding the button on the **ORIGINAL** remote until the **TV** button on the ADB remote blinks twice.

**if the learning failed, the TV button will emit on long blink. You will have to repeat step 6.*